



PENTAX MOUNT ADAPTER K OPERATING MANUAL

How to use the PENTAX mount adapter K

This adapter is used to attach the conventional TAKUMAR screw-mount lens to the PENTAX K mount camera.

The distance scale of the lens can be used as it is and picture taking is possible up to infinity. However, the automatic diaphragm of the lens will not function, so meter reading must be made with the lens aperture stopped down.

- (1) Fit in the adapter, matching the red dot of the adapter with the red dot of the body mount.
- (2) Turn the adapter clockwise until it stops (65°) by using a ball-point pen or the like to lock it.
Then screw-mount lenses can be used.
- (3) To remove the adapter, push the spring with a ball-point pen and turn the adaptor counter-clockwise until it stops.



PENTAX マウントアダプター K の使い方

従来のタクマーねじマウントレンズをペンタックス K マウントカメラに取り付けるためのアダプターです。

レンズの距離目盛はそのまま使用でき無限遠まで撮影ができます。ただし、自動絞りは使えなくなりますので測光は絞り込み測光になります。

- ① アダプターの赤点をボディーマウントの赤点に合わせてはめ込みます。
- ② ボールペンの先などで、右へ止まるまで [65°] 回すとロックされます。これでねじマウントのレンズが使用できます。
- ③ アダプターを外す時はボールペンの先などでバネを内側に押し、アダプターを左に止まるまで回し、取り出します。

